

ETAS GmbH • PO Box 30 02 20 • 70442 Stuttgart

ETAS GmbH

ETAS Customer Information

Borsigstraße 14
70469 Stuttgart
Phone +49 711 3423-0

Disconnecting connected ES800 modules

Dear Customer,

In order to ensure a trouble-free connection of several ES800 modules, a high-precision stacking mechanism is being used.

To disconnect connected modules, please follow these instructions:

**CAUTION!*****Possible damage or destruction of electronics!***

Only connect the base module with the modules of the system in the de-energized state! Only stack the modules in the de-energized state or in standby mode!

- Disconnect the module stack from the voltage supply.

**CAUTION!*****Risk of crushing of fingers between the lateral levers for unlocking and the housing of the module!***

Lift the lateral levers for unlocking the module only evenly!

- Fold the two lateral levers up for unlocking the upper module.
- Lift the front part of the upper module.
- Release the two previously folded lateral levers.

The upper module is still locked in place by the rear system plug.

- Press the front part of the upper module down.

The upper module gets separated from the lower module.

- Lift the upper module from the module stack and put it in a safe place.
- Put the protective cap of the module onto the lower system plug of the disconnected module.
- Close the protective flap of the lower module/upper module of the module stack.

F-00K-800-062

Customer_Information_Unblocking_V01.doc